


T E C H N I C A L D A T A S H E E T

Quantum Diamonds

Nitrogen-vacancy (NV) diamond for quantum sensing, computing & metrology



C O N T E N T S

- 01** Product Overview
- 02** Product Specifications
- 03** Application
- 04** Handling & Storage

A C S M A T E R I A L , L L C

959 E Walnut St., Suite 100
Pasadena, CA 91106, USA
Phone (866) 227-0656
Fax (781) 518-0284
contact@acsmaterial.com
Revision 062526

Product Overview

The **nitrogen-vacancy (NV) center** is a unique atomic-scale defect in diamond, formed when a nitrogen atom substitutes for a carbon atom adjacent to a lattice vacancy. This defect endows the diamond with remarkable optical and electronic properties, making it a foundational element in emerging quantum technologies. NV centers exhibit stable fluorescence and exceptionally long electron-spin coherence times — and operate at room temperature, even in ambient or biological environments — enabling advanced applications in magnetic-field sensing, bioimaging, and quantum information processing.

Due to these properties, NV-diamond platforms have attracted significant interest from both academia and industry, garnering attention from leading organizations such as Lockheed Martin and Bosch. **ACS Material grows, cuts, polishes, and quantum-characterizes every diamond in house**, so the NV concentration and coherence times you order are verified before shipping.

Product Specifications

ACS Material currently offers **five grades** of quantum diamonds, each grown and characterized for a specific class of NV experiments.

Single NV Diamond — Q-DNV-Ran(S)

Individually addressable, randomly distributed single NV centers with long T2 coherence.

FEATURES

Excellent coherence: $T_2 \approx 200 \mu\text{s}$ • Controllable concentration: 1–10 per μm^2

QUANTUM PROPERTIES

[NV]	T1	T2	T2*
1 per μm^2	$\approx 5 \text{ ms}$	$\approx 200 \mu\text{s}$	$\approx 0.5\text{--}8 \mu\text{s}$

Single NV Diamond — Q-DNV-Array(S)

Lithographically patterned NV arrays for deterministic positioning and deep, long-lived spins.

FEATURES

Depth controllable (5–100 nm) • Patterned for easy positioning of NV centers • Long coherence time, deep NV centers ($T_2 > 200 \mu\text{s}$)

QUANTUM PROPERTIES

[NV]	T1	T2	T2*
0.25 per μm^2	$\approx 5 \text{ ms}$	100–200 μs	$\approx 0.3\text{--}2.2 \mu\text{s}$

NV depth $d > 50 \text{ nm}$

NV Ensemble Diamond — Q-DNV-2D(E)

Near-surface 2D NV ensembles with oxygen-terminated surfaces for sensitive, shallow sensing.

FEATURES

Depth controllable (5–100 nm) • Controllable concentration • Oxygen-terminated surface

QUANTUM PROPERTIES

[NV ⁻]	T1	T2	T2*
10 ¹¹ –10 ¹³ per cm ²	1–5 ms	10–100 μs	≈ 0.3–0.8 μs

NV depth *d* > 50 nm

NV Ensemble Diamond — Q-DNV-Bulk(E)

High-density bulk NV ensembles for maximum signal in magnetometry and quantum sensing.

FEATURES

Depth controllable (5–100 nm) • Controllable concentration • Oxygen-terminated surface

QUANTUM PROPERTIES

[NV ⁻]	T1	T2	T2*
10–300 ppb	≈ 5 ms	50–200 μs	≈ 0.7–1 μs

Electronic-Grade Diamond — Q-DNV-ELD

Ultra-pure {100} CVD substrate with < 5 ppb nitrogen — the pristine canvas for NV creation.

Electronic-grade diamond features nitrogen impurity levels below 5 ppb and ultra-low background fluorescence, making it highly suitable for advanced quantum research.

QUANTUM PROPERTIES

Faces	Roughness	¹³ C	[N]	[B]	[NV ⁻]
{100}	Ra < 3 nm	1.1%	< 5 ppb	< 1 ppb	< 0.05 ppb

ORDERING INFORMATION

SKU Chart — Standard Sizes

Type / Size	2×2×0.5 mm ³	4×4×0.5 mm ³
Single NV diamond — Q-DNV-Ran(S)	SKU# QDMNV001	SKU# QDMNV002
Single NV diamond — Q-DNV-Array(S)	SKU# QDMNV003	SKU# QDMNV004
NV ensemble diamond — Q-DNV-2D(E)	SKU# QDMNV005	SKU# QDMNV006
NV ensemble diamond — Q-DNV-Bulk(E)	SKU# QDMNV007	SKU# QDMNV008
Electronic-grade diamond — Q-DNV-ELD	SKU# QDMNV009	SKU# QDMNV010

Custom sizes, NV depths, and concentrations are available on request.

III Application

— Quantum communication

Single-photon NV emission for secure key distribution and quantum repeaters.

— Magnetic field sensing

Vector magnetometry with nanoscale resolution at room temperature.

— Electric field sensing

Stark-shift detection of local electric fields with high sensitivity.

— Temperature sensing

Sub-degree thermometry for biological and microelectronic systems.

— Maser

Room-temperature solid-state masers built on dense NV spin ensembles.

— Quantum gyroscope

Rotation sensing through coherent precession of NV electron spins.

IV Handling & Storage

QUALITY ASSURANCE

Every diamond is characterized in-house by confocal photoluminescence mapping and optically detected magnetic resonance (ODMR). The NV⁻ concentration and coherence times (T₁, T₂, and T₂^{*}) are measured and recorded before each unit ships.

HANDLING & STORAGE

Handle the polished faces with clean, non-metallic tweezers and store the diamonds in a dry, dust-free container. They may be cleaned with isopropanol or a standard acid protocol; avoid mechanical abrasion of the polished surfaces.

DISCLAIMER ACS Material, LLC believes that the information in this Technical Data Sheet is accurate and represents the best and most current information available to us. ACS Material makes no representations or warranties, either express or implied, regarding the suitability of the material for any purpose or the accuracy of the information contained within this document. Accordingly, ACS Material will not be responsible for damages resulting from use of or reliance upon this information.